


# DATA SHEET PROPORTIONER FD4000 GEN III

# FOR STATIONARY EXTINGUISHING SYSTEMS.



# 1. TECHNICAL DATA.

Туре	FD4000/0,5-S	FD4000/1-S	FD4000/3-S	FD4000/3/3-S	
Proportioning rate	0.5 %	1%	3 %	3% + 3% = 6%	
Approvals	_	FM Approval PR452158 2)			
Flow directions of	Horizontal: "left → right" or "right → left"				
water motor	Vertical: "top → bottom" or "bottom → top"				
Min. water flow rate 1)	250 l/min	250 l/min	280 l/min	380 l/min	
Min. water flow rate FM	-	400 l/min	440 l/min	-	
Max. water flow rate	4000 l/min				
Operating temperature 3)	5° C – 50° C (standard version)				
	5 °C – 80 °C (High-Temp version) ×)				
Storage temperature	-20 °C − 80 °C				
Operating pressure	5 – 16 bar				
Weight 4)					
Freshwater version	104 kg	111 kg	168 kg	222 kg	
Seawater version x)	181 kg	188 kg	245 kg	299 kg	
ATEX classification x)	(☑) II 2G Ex h IIC T4 Gb				
for +5 °C ≤ T <sub>a</sub> ≤ +60 °C					

<sup>1)</sup> The nominal proportioning rate is achieved when reaching the specified minimum figure. Indication for proportioning of fluid Newtonian foam agents at operating pressure of 5 bar. For more detailed information, refer to page 2, item 3. "Minimum water flow rate".

X) Optional equipment.







www.firedos.com

ssued/modified: A. Hulinsky on: 20.01.2021 Version no.: 06 Approved: A. Hulinsky on: 20.01.2021


 $<sup>2)</sup> For information \ regarding \ FM \ Approved \ data, \ please \ refer \ to \ www.approvalguide.com.$ 

<sup>3)</sup> Operating temp. is the max. ambient and medium (foam and extinguishing water) temperature. Max. foam agent temp. is generally limited to 50 °C. 4) Weight indications are based upon the standard version in dry condition. Special versions will differ.




#### 2. PRESSURE LOSS.


Indication valid for operating pressure of 10 bar. For more information on different system conditions or proportioning rates, please contact us.



#### 3. MINIMUM WATER FLOW RATE.

The following diagrams show the effect of the operating pressure and foam agent viscosity on the minimum water flow rate (valid for viscosities in the graph at para. 4).






#### Comment:

The values can be reduced to approx. 35% by an optional flow reduction. The values increase by approx. 40% in the high-temp version. For values at other proportioning rates, please contact us.



#### 4. FOAM AGENT VISCOSITY.

**FireDos** proportioners are suitable for all foam agents available on the market. For reference regarding units with an FM Approval, please find the corresponding/associated range of dynamic viscosity below (www.approvalguide.com). Contact us if the dynamic viscosity of your foam agent is higher than the values in the diagram. **Do not hesitate to request our support for the correct dimensioning of your suction line.** 




# 5. MATERIALS.

	Freshwater version	Seawater version			
Water motor 4)	Cast Aluminium G-AISi7Mg HC-coated, AIMgSi1 HC-PTFE-coated, stainless steel 316 / 316Ti, POM, PVDF, NBR, FKM	Cast Bronze G-CuSn10, stainless steel 316 / 316Ti, Aluminium-Bronze CuAl10Fe5Ni5-C-GC, POM, PVDF, NBR, FKM			
Proportioning pump 4)	Stainless steel 316 / SS316Ti / 318 LN, POM, FKM, Aluminium oxide ceramic Al2O3, Aluminium-Bronze CuAl10Ni5Fe5-C-GC				
Pipework <sup>4)</sup>	Stainless steel 316 / CF8M / SS316Ti, PTFE,				
Support frame	Stainless steel 304 / 316				


<sup>4)</sup> media-exposed materials

#### 6. FLOW DIAGRAM.

#### Proportioning rate 0.5% / 1% / 3%



Proportioning rate 3% + 3% = 6%




- 1. Water motor
- 2. Proportioning pump
- 3. Coupling
- 4. 2-way ball valve "Flushing/Priming"
- 4.1 "Flushing/Priming" pump head I
- 4.2 "Flushing/Priming" pump head II
- 5. Filter in the flushing line
- 6. Check valve in the flushing line
- 7. Non-return flap in the suction line
- 8. Air bleed valve
- 9. Air bleed hose
- 10. Shut-off valve pressure gauge
- 11. Pressure gauge
- 12. 3-way ball valve "Returning/Proportioning"
- X) Special version

- 12.1 "Returning/Proportioning" pump head I
- 12.2 "Returning/Proportioning" pump head II
- 13. Check valve in the proportioning line
- 14. Pulsation damper
- 15. Standard scope of supply of *FireDos* proportioner
- 16. Revolution counter with flow rate display  $x^{3}$
- 17. Flow meter for return line x)
- 18. Pressure sustaining valve for return lx)
- 19. 2-way ball valve in return line  $^{\times)}$
- 20. Foam agent supply
- 21. Shut-off valve in the suction line
- 22. Extinguishing water supply
- 23. Water filter



#### 7. EXAMPLE FIGURE / DIMENSIONS.



Туре	FD4000/0,5-S	FD4000/1-S	FD4000/3-S	FD4000/3/3-S	
Proportioning rate	0.5 %	1%	3%	3% + 3% = 6%	
Connection water motor A	Optionally: Flange DIN EN 1092-1, DN150 PN16 RF Flange ASME B16.5, 6" Class 150 RF				
Installation length water motor X 5)	500 mm				
Connection suction line B	2" MT BSP 2" MT NPT <sup>X)</sup>	2" FT BSP 2" MT NPT <sup>X)</sup>	2.1/2" FT BSP Flange ASME B16.5 2.1/2" Class 150 <sup>X)</sup>	2x 2.1/2" MT BSP 2x Flange ASME B16.5 2.1/2" Class 150 <sup>X)</sup>	
Connection return line C	3/4" FT BSP 3/4" MT NPT <sup>X)</sup>	1" FT BSP 1" MT NPT <sup>X)</sup>	1.1/4" FT BSP 1.1/4" MT NPT <sup>X)</sup>	2x 1.1/4" FT BSP 2x 1.1/4" MT NPT <sup>X)</sup>	
Length L <sup>5)</sup>	1045 mm	1060 mm	1200 mm	1280 mm	
Width W <sup>5)</sup>	625 mm	760 mm	860 mm	1050 mm	
Height H <sup>5)</sup>	485 mm	500 mm	550 mm	650 mm	

All figures are approximate only and depend on the particular version/equipment options.

Please allow sufficient accessibility of the proportioner for maintenance work. For assistance to ensure sufficient accessibility, please refer to our planning manual for proportioners.

# 8. MANUFACTURER.

*FireDos* GmbH, Auf der Kaulbahn 6, 61200 Woelfersheim, Germany Phone +49 (0) 6036 9796-0, Email: info@firedos.de

We reserve the right to make modifications at any time.

www.firedos.com

X) Special version.

<sup>5)</sup> Further accessories to the proportioner may require more installation space.